



ASSEMBLY INSTRUCTION

NEUTRIK tinyPLUG | 3.5 mm right-angle stereo plug

- A** Slide the boot onto the cable.
- B** Prepare cable as shown.
- C** Solder the wire ends .
- D** Assembly of strain relief:
- ① Bend cable by 90° towards the sleeve contact.
 - ② Position the chuck on the connector body.
 - ③ Close the strain relief (break away part X if cable O.D. > 3.2 mm)
- E** Place the shell halves onto the connector body.
- F** Slide the bushing up to the thread and tighten it.

NEUTRIK AG LI T: +423 / 237 24 24 F: +423 / 232 53 93
 NEUTRIK USA Inc. USA T: +1 704 / 972 3050 F: +1 704 / 438 9202
 NEUTRIK (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983 / 811 439
 NEUTRIK Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131 / 280 830

NEUTRIK France FR T: +33 1 / 4131 6750 F: +33 1 / 4131 0511
 NEUTRIK Tokyo Ltd. JP T: +81 3 / 3663 4733 F: +81 3 / 3663 4796
 NEUTRIK Hong Kong Ltd. HK T: +852 / 2687 6055 F: +852 / 2687 6052

Draft. Nr.: BDA 128 / 3102M1241 | Update: 11.01.2013 | Data subject to change without prior notice. ©2013 NEUTRIK®. ALL RIGHTS RESERVED. NEUTRIK® are registered trademark.

www.neutrik.com

NEUTRIK®